



Quick Reference Guide

Install Diver-Gate Driver – Windows XP

Introduction

The driver for the Diver-Gate(M) is not installed with Diver-Office. In most cases the driver will be automatically installed once the Diver-Gate(M) is connected to your computer. This may take a few minutes.

In case the driver is not installed automatically follow the steps below. This document outlines the most common workflow for Windows XP for installing the drivers for the Diver-Gate(M).

Prerequisites

Download the Diver-Gate(M) drivers from:

- http://trials.swstechnology.com/software/Diver-Office/2016/Diver-Gate_Drivers_Setup.exe


Installation

1. Plug the USB cable into the Diver-Gate(M) and into a free USB port on the computer.
2. Turn on the Diver-Gate(M) and wait approximately 30 seconds until the Status light on the Diver-Gate(M) starts blinking.
3. Windows should detect new hardware. When asked to search for software select “No, not this time” and click “Next.”






4. Select “Install from a list or specific location (Advanced)” and click “Next”.




5. Browse to the location where the gserial driver was extracted. Once the location has been selected, press “Next”.





6. When the “Hardware Installation” dialog appears select: “Continue Anyway.”



7. After a few seconds the following dialog should appear. Clicking “Finish” should complete the installation of the gserial driver:

